ITEM 10702 TALKING VIBRATING ALARM CLOCK

Operating Instructions
1. Take batteries from battery compartment, remove plastic foil and replace batteries. Ensure battery polarity is correct.
2. Press the Top button on unit and time will be announced.
3. Open front hinged leg to show control buttons.
4. In normal time display, press 'MODE' button to choose between chime On/Off, alarm On/Off and vibration On/Off.
5. When chime on, the ⌁ symbol will be appeared. When the alarm on, the ⌁ symbol will appear.
6. Continue to press 'MODE' button to choose the alarm sound.
7. **Press 'SET' to change the sound into either in 'Pip', 'Dong' or "Rooster" sound.**

Set Time
1. Press 'MODE' button to set the time set mode.
2. Press 'MODE' button to set the year, month and date.
3. Press 'SET' button to change the day until the correct day displayed. Hour is flashing, press 'SET' to set hour.
4. Press 'MODE' button when the correct hour is displayed. Minute is flashing, press 'SET' button to set minutes.
5. Press the 'MODE' button and then press 'SET' to choose the 12 hour mode display.

Set Alarm Time
1. Press 'Mode' button to set the alarm time.
2. When hour is flashing, press 'SET' button to set hour.
3. Continue to press 'MODE' button to set the minute.
4. When minute is flashing, press 'SET' button to set minute.

Countdown Timer
1. Press 'MODE' button to set the countdown timer.
2. Press 'SET' button to set the countdown hour.
3. Then, press 'MODE' button to set the countdown minute.
4. Press 'SET' to change the countdown minute.
5. Last, press 'DATE' to turn On/Off the countdown timer.

Note the unit will "talk" at each mode setting to identify the position of settings.
The unit can be stood up using the drop down hinged back leg.

If the LCD screen fades and/or the sound becomes weak or the function is abnormal, please change the battery. (2pcs AAA batteries).

CE European Community Directive 2004/108/EC

European Community Directive 2002/96/EC